



DOWEX Ion Exchange Resins

Procedure for Acid Cleaning of Mixed Bed Resins

Acid treatment of a mixed bed is used to remove inorganic contaminants such as metals and also silica. It can, therefore, be applied to both cation and anion components in-situ.

The recommended procedure is as follows. The acid concentration should be increased gradually to avoid excessive osmotic stress to the resin:

1. Exhaust the mixed bed.
2. Pass upflow 1 bed volume 5 percent HCl solution contact time 30 minutes.
3. Pass upflow 1 bed volume 10 percent HCl solution contact time 30 minutes.
4. Leave to soak overnight with occasional air injection to facilitate contacting of the acid with the resins.
5. Displace/rinse the acid downflow with min. 5 bed volumes DI water.
6. Backwash the resins to separate and then regenerate as normal.
7. Repeat step 6 to ensure resins are properly separated and regenerated.

DOWEX

Ion Exchange Resins

LENNTECH

info@lennotech.com Tel. +31-152-610-900

www.lennotech.com Fax. +31-152-616-289

WARNING: Oxidizing agents such as nitric acid attack organic ion exchange resins under certain conditions. This could lead to anything from slight resin degradation to a violent exothermic reaction (explosion). Before using strong oxidizing agents, consult sources knowledgeable in handling such materials.

NOTICE: No freedom from any patent owned by Seller or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace and disposal practices are in compliance with applicable laws and other governmental enactments. Seller assumes no obligation or liability for the information in this document. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

Published May 2002.

